

# VIBRATION KEYCHAIN

AMU9952-09B

This vibration keychain lets you set the clock vibrate without disturbing others around you at the preset time; offering a truly personal alarm. Its lightweight design lets you carry it everywhere you go. Its features include:

- Clock Alarm — vibrates at a time you set.
- Snooze Control — temporarily silences the alarm twice every 4 minutes.
- Timer — counts down from a specified time up to 23 hours, 59 minutes, 59 seconds.

## SETTING THE TIME

1. Press **MODE**, and **T. SET** displays on LCD and the hour digits flash.
2. Repeatedly press (or hold down) **UP/SNZ** to set the hour.
3. Press **SET/ALM** to store the hour. The minute digits flash.
4. Repeatedly press (or hold down) **UP/SNZ** to set the minute.
5. Repeatedly press **MODE** until the current time displays.

### Notes:

- While setting the time, if you do not press a key for about 30 seconds, the clock returns to the current time display.
- The clock uses the 12-hour format. **PM** appears for a PM hour.

## SETTING THE ALARM TIME

You can set the clock to vibrate to remind you of a daily event ( such as a meeting ) ; follow these steps to set the vibration alarm.

1. Press **MODE** twice. **AL.SET** and 12:01 or the preset alarm time appear. The hour digits flash.
2. Repeatedly press (or hold down) **UP/SNZ** to set the alarm hour.
3. Press **SET/ALM**. The minute digits flash.

## OPERATION INSTRUCTION - Please read before using this equipment

4. Repeatedly press (or hold down) **UP/SNZ** to set the alarm minute.
5. Repeatedly press **MODE** until the current time displays.
6. Press **SET/ALM** to turn on the alarm. " " " appears.

To check the alarm time, repeatedly press **MODE** until **AL.SET** and the set alarm time appear.

When the preset alarm time reaches, the clock repeatedly vibrates 2 seconds and stops 3 seconds for 1 minute then automatically turns off. To silence the alarm sooner, press any key.

If you do not want the alarm to sound again the next day, press **SET/ALM** to turn off the alarm. " " " disappears.

### Note:

- While setting the alarm time, if you do not press a key for about 30 seconds, the clock returns to the current time display.

## USING SNOOZE

To turn on snooze, press **UP/SNZ** after setting the alarm time. **SNOOZE** appears.

When the preset alarm vibrates on and off for 1 minute then automatically turns off, or you can press any key to temporarily stop the alarm. With snooze turned on, after 4 minutes, the alarm vibrates twice in every four minutes.

To turn off snooze, press **UP/SNZ** again.

## USING THE COUNTDOWN TIMER

The countdown timer lets you set a specific time to count down from (up to 23 hours, 59 minutes, 59 seconds).

1. Press **SET/ALM** to turn on the alarm, " " " appears.
2. Repeatedly press **MODE** until **TIMER** and 0:00 00 appear. The hour digits flash.

**Note:**

- While setting the timer, if you do not press any key within about 30 seconds, the clock automatically returns to the current time display.
3. Press or hold down **UP/SNZ** until the desired count down hour displays.
  4. Press **SET/ALM**. The minute digits flash.
  5. Press or hold down **UP/SNZ** to set the desired count down minute.
  6. Press **SET/ALM**. The second digits flash.
  7. Press or hold down **UP/SNZ** to set the desired count down second.
  8. Press **START** to start countdown. The timer begins to countdown. To stop the countdown, press **START** again. When the timer reaches 0:00 00, it vibrates on and off for 1 minute. To stop the alarm, press any key.
  9. To reset the timer to 0:00 00, press **SET/ALM**. If the countdown timer is running, press **START** to stop counting then press **SET/ALM** to reset the timer to 0:00 00.

**RESETTING THE KEYCHAIN**

If the clock displays segmented digits, does not work properly, or locks up, you can reset it by using a pointed object, such as a straightened paper clip, to press **RESET** on the back of the keychain.

**REPLACING THE BATTERIES**

Your clock requires two AG13 batteries for power. If the keychain stops operating properly or the display dims, or vibration slows down, replace the batteries. Follow these steps to install batteries:

1. Slide the battery compartment cover on the back in the direction of the arrow to remove it.
2. Insert two AG 13 batteries in the compartment as indicated by the polarity symbols (+ and -) marked inside.
3. Replace the cover.

Wait for about 5 seconds after the batteries are installed, the clock vibrates. 12:00 00 and " " appear.

**Note:**

- The default alarm time is set to 12:01. Press **SET/ALM** to turn off the alarm before you set the time.