QUICK REFERENCE

VibraLITE 2TM

Selection of Vibration, Beep, Both or off signal

Press MODE button until in the Calendar Clock mode. Repeat Pressing START/STOP button to select desired function.

Icon(s) at top right of display will indicate function:

Vibration, Beep, Both, Off. A quick check to see what is activated is to push the MODE button in the Calendar Clock mode. Whatever feature is set will respond each time you push the MODE button.

Setting of Hours & Minutes for

Countdown Timer, Alarms

Press MODE Button to rotate to mode you wish to set. TR for Timer

A1 or A2 for Alarms

Press and Hold LAP/RESET button until HOUR digits blink. TO select Hour wanted, Press START/STOP button.

Press MODE button to change to minute setting.

While minutes digits are blinking, press START/STOP button to select minutes wanted.

Press LAP/RESET button to set time.

In Countdown Timer Mode,

A STATE OF

the display stops blinking when set. To start countdown, press START/STOP button. To pause countdown, press START/STOP button. In Alarm Mode, the alarm indicator icon shows which alarm is activated.

Hourly Alert Setting

Press MODE button until in Alarm mode.
Repeat Pressing START/STOP button until the Hourly chime icon shows. (located beside the A2 icon)

8R02-LG069NA-NON



Www.TabTimer.com.au
1300 TAB TIMER
(1300 822 846 37)
ABN: 99 137 415 948