


Digital Clock Instruction Manual

Main features

- ✓ Date and time without abbreviation, easy to read
- ✓ 5 groups of alarm + 3 groups of medication reminder alarm setting, alarm volume adjustment
- ✓ Auto and manual brightness adjustment
- ✓ 8 languages available
- ✓ Three user interface: digital clock UI + analog clock UI + color bar digital clock UI + digital photo frame features
- ✓ Adding remote control for convenient use



Display View

Choose display view by pressing Middle button (**OK**) 2s to switch between view 1, 2 and 3.

1. Digital clock UI:



2. Analog clock UI



3. Digital clock UI with color bar



Setting:

Press **Menu** button to enter screen menu. Use **UP** and **DOWN** button to highlight the line to apply changes. Use **LEFT** and **RIGHT** button to underline the text for adjustment. When underlined, use **UP** and **DOWN** button to make changes. Press **MENU** button to close changing mode.

Language Set	<	English	>
Time Set	<	21:12:33	>
Date Set	<	04-03-2019	>
Time Mode	<	24 Hour	>
Date Mode	<	Month-Day-Year	>
Auto Dimming	<	Off	>
Volume Set	<	30	>
Alarm Set	<		>
Medicine Reminder	<		>
Factory reset	<	V5.3.3	>

Menu

Line 1-Language Set

Press **OK** button and Choose preferred language using **LEFT** or **RIGHT** button. Possible options English / French / German / Dutch / Italian / Polish / Spanish / Welsh.

Press **MENU** button to exit from menu screen

Line 2-Time Set

Press **OK** button to enter the time set.

Press **LEFT** or **RIGHT** button to underline the hour <07:10> change the hour by using **UP** or **DOWN** button.

Press **LEFT** or **RIGHT** button to underline the minutes <07:10> change minutes by using **UP** or **DOWN** button.

Press Middle button **OK** to confirm changes and **MENU** button for exit menu screen.

Line 3-Date Set

Press **OK** button to enter the date set.

Before setting date select preferred Date Mode (see description under Date Mode)

After Date Mode is set press **LEFT** or **RIGHT** button to highlight and underline date/month/year. Using **UP** or **DOWN** button set correct

date/month/year.

Press **MENU** button to exit from menu screen

Line 4-Time Mode: < 12 Hour / 24 Hour >

Press **OK** button or press **LEFT** and **Right** button to choose 24 hours/12 hours option

Press **MENU** button to exit from menu screen

Line 5- Date Mode: < Day-Month-Year, Month-Day-Year >

Press **OK** button or press **LEFT** and **RIGHT** button to choose one of two options <Day-Month-Year> or <Month-Day-Year>

Press **MENU** button to exit from menu screen

Line 6-Auto Dimming: < Auto/Mid/Low/Off >

Press **OK** button or press **LEFT** and **RIGHT** button to choose brightness level (Off/Mid/Low/Auto), press **MENU** button to exit from menu screen

Line 7-Volume Set

Press **OK** button or press **LEFT** and **Right** button to choose the best volume level. Volume level from 0 to 30, 30 is the highest volume and 0 is mute.

Line 8- Alarm Set

Press **OK** button to enter the alarm clock setting.

There are 5 groups of alarms, set the time and alarm frequency. After finish setting, press **MENU** to exit.

Line 9- Medicine Reminder

Press **OK** button to enter the medicine reminder setting.

There are 3 groups of medicine reminders (morning/afternoon/evening medicine reminder), set the time and reminder frequency. After finish setting, press **MENU** to exit.

Line 10-Factory Reset

Press **OK** button, it will remind **YES** or **NO** for factory reset, choose **YES**, all setting come back to factory default mode, choose **NO**, it keeps all of your current setting. press **MENU** to exit.

Digital Photo Frame Features

Put images or videos into the U disk, then, insert the U disk on the clock USB port (when you are in the clock interface), it will play photo and video automatically.

Image resolution should be 800*600. support image format: JPG, JPEG.

Support video format: mp4, avi, rmvb.

Tip: Please use genuine USB flash Drive, maximum support capacity is 32GB.