


DAY CLOCK USER INSTRUCTIONS

Easy Read + Main Features:

- ✓ *Non-abbreviated Date, Day and Time*
- ✓ *12 Programmable Alarms*
- ✓ *Programmable reminder :Meal, Medicine, Clinic, Shower, Gardening, Cleaning, Appointment and Walk dog*
- ✓ *Automatic Brightness Adjustment + Manual Brightness*

Adjustment

- ✓ *8 Languages*
- ✓ *Choose to display Morning, Afternoon, Evening and Night or not*
- ✓ *Add Remote Control Help Easy to Set*
- ✓ *12.1" High-Resolution Digital Photo Frame*




Settings:

Making Adjustments Press the **MENU** button to display the on screen menu;

Please Note:Changes can only be made to the line when highlighted in brackets and Red font. Use the **UP** or **DOWN** button to highlight the line to apply changes.

Use the **LEFT** or **RIGHT** buttons to Red font the text for adjustment.



Line 1- Set Time:

Press **"OK"** to enter into the time setting. While the digit is Red font the hour<04:47>,Press UP or DOWN to change the time.when you get the correct digit,Press **"OK"** to save.Then ,press **"OK"** and LEFT or RIGHT to highlight the minutes <04:47>.Press UP or DOWN to change the time.when you get the correct digit,Press **"OK"** to save(Press **MENU** to exit)

Line2 - Set Date:

Select "Set Date "so that it is highlight in red.Press "OK "to enter into the date setting Font the Day:<08-01-2018>or<01-08-2018>,use UP or DOWN to adjust date. when you get the correct digit,Press **"OK"** to save, Then press **"OK"** and LEFT or RIGHT to highlight Month/Year <08-01-2018>Press UP or DOWN to change the date.when you get the correct digit,Press **"OK"** to save(Press **Menu** to exit)

Line3 - Time Mode:12/24HourTime

Press "OK" to Red font <12 Hours>.LEFT or RIGHT to Select Time Mode between 12-Hours and 24-Hours

After the modifications are completed, Press "OK" to save(Press **Menu** to exit)

Line4 - Date Mode:<Day-Month-Year>or<Month-Day-Year>

Press "OK" to Red font.LEFT or RIGHT to Select Date Mode .

After the modifications are completed,Press "OK" to save(Press **Menu** to exit)

Line5 - Language

Press "OK" to Red font.Then Press LEFT or RIGHT to Select 8 language.

After the modifications are completed,Press "OK" to save(Press **Menu** to exit)

Line6 - Automatic Brightness:

The default is turn on the Auto Brightness,Press "OK" to Red font then Turn to manual adjustment brightness from Level 1 to Level 5 and turn **on** the Auto Brightness .LEFT or RIGHT Select brightness

When you get the brightness you want,Press "OK" to save(Press **Menu** to exit)

Line7 - Alarm Status:

On Line 7 , Press "OK" to enter the alarm settings -- Press "OK" to

Add Timer-- Press "OK" to enter Time 1 (Timer1 to Timer 12) alarm setting -- Press "OK" to set Alarm Time,Date,Frequency and Tag

(Tag:Meal,Medicine,Clinic,Shower,Gardening,Cleaning,Appointment and Walk dog)

Note:You need to turn on the **start timer <On>** then the alarm will sound

After the modifications are completed,Press "OK" to save(Press **Menu** to exit)

Line8 - Volume

Press "OK" enter Volume adjustment,from 1--5 The sound will be bigger and bigger

When you select the volume, Press "OK" to save(Press **Menu** to exit)

Line9 - Set Chime

Press "OK" enter Hourly time setting, Select the time you want to on-time alarm , press the "OK" button to confirm the selection, and when the number turns red, the selection is successful. (Press **Menu** to exit)

Digital Photo Frame Features:

When you are in the clock interface, after inserting the SD card, press "OK" to enter the playback image and video.

support video format: mp4, avi, rmvb. support picture format: Jpg, jpeg

Tip: Please use genuine SD Card and USB Flash Drive,

Maximum support capacity: 64GB